




# Sony Cyber-shot DSC-HX300 Motherboard Replacement

This guide will show how to replace the motherboard.

Written By: Elizabeth Surface



## INTRODUCTION

If the Sony Cyber-shot DSC-HX300 is failing to power, while it has a full battery and the LCD screen works, then it is possible that the motherboard has gone out and needs to be replaced.



### TOOLS:

- [Small Phillips Head Screwdriver](#) (1)
- [iFixit Opening Tools](#) (1)
- [Magnetic Project Mat](#) (1)



### PARTS:

- [Sony Cyber-shot DSC-HX300 Motherboard](#) (1)

## Step 1 — Battery



- ⚠ Make sure the camera is powered off
- Turn the camera upside down. This is a view of the bottom of the camera.

## Step 2



- Push battery cover away from the camera.

## Step 3



- Push the blue tab that secures the battery. The battery will then spring out.

## Step 4



- Remove the battery.



## Step 5 — Motherboard



 Make sure to remove the battery before disassembly to prevent electrocution.


- Remove the 3 (4 cm) Phillips head screws located on the back of the camera.
- Remove the 2 (4 cm) Phillips head screws on the right side of the camera.
- Turn the camera upside down to remove the remaining the 3 (4 cm) Phillips head screws holding the plastic camera housing together.

## Step 6






- Using a plastic opening tool, separate the plastic camera housing.

## Step 7



- Disconnect the ribbon wire attaching the screen to the camera.



## Step 8



- Carefully remove the 7 ribbon wires connected to the mother board.
- Remove the 2 (5 cm) Phillips head screws on the speaker mounting bracket.
- Remove the 3 (4 cm) Phillips head screws that secure the motherboard to the camera.
- Lift up on the speaker mounting bracket to remove it.



## Step 9



- Carefully disconnect the ribbon wire connecting the HDMI port to the Motherboard.
- Once the Motherboard is removed the replacement can be installed.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-27 01:00:03 PM.